


WHITE WIRE FROM OUTLET BOX FIGURE 1



GREEN OR BARE COPPER WIRE(OPOUNDING WIRE) FIGURE 3



## CAUTION:

"Warning", "This product is to be installed by a qualified electrician only." "Suitable for dry locations only"

## CAUTION:

- 1.- Wrong lighting installation can be dangerous for your safety.
- 2.- Before starting, disconnect the power by turning off the general switch of the electric installation.
- 3.- Install light bulbs (not provided) that must not exceed markings on the fixture.
- 4. To change the bulbs, disconnect the power by turning off the general switch and wait for the bulbs cool down.
- INSTALLATION:
- 1.- Make electrical connections, carefully read the Electrical Connection section.
- 2.- Assemble lighting onto the outlet box as shown on back page
- ELECTRICAL CONNECTIONS: (See fig. 1,&2 ,&3 ,&4)
- 1.- Connect the white wire from the fixture to the white wire of the electric installation.
- 2.- Connect the black wire from the fixture to the black wire of the electric installation.
- 3.- Connect the grounding conductor from the fixture to the grounding wire of the electric installation.
- 4.- Spread out the electrical wires so that the black ones are on one side of the outlet box and the white ones are on
- the other side, and carefully introduce them into the outlet box.

